

DMX CHANNELS

1 CANALI

MODE 1 Ch	FUNCTION	DMX Value
1	DIMMER 0~100%	000 - 255

2 CANALI

MODE 2 Ch	FUNCTION	DMX Value
1	DIMMER 0~100%	000 - 255
2	DIMMER SPEED MODE Preset dimmer speed from display menu Dimmer speed mode off Dimmer speed mode1 (fast speed) Dimmer speed mode2 (middle speed) Dimmer speed mode3 (slow speed)	000 - 051 052 - 101 102 - 152 153 - 203 204 - 255

5 CANALI

MODE 5 Ch1	FUNCTION	DMX Value
1	DIMMER 0~100%	000 - 255
2	CTO 2800K - 3000K 3000K - 3200K 3200K - 3400K 3400K - 3600K 3600K - 3800K 3800K - 4000K 4000K - 4200K 4200K - 4400K 4400K - 4600K 4600K - 4800K 4800K - 5000K 5000K - 5200K 5200K - 5400K 5400K - 5600K 5600K - 5800K 5800K - 6000K 6000K - 6200K 6200K - 6400K 6400K - 6600K 6600K - 6800K 6800K - 7000K 7000K - 7200K 7200K - 7400K 7400K - 7600K 7600K - 7800K 7800K - 8000K 8000K - 8200K 8200K - 8400K 8400K - 8600K 8600K - 8800K 8800K - 9000K 9000K - 9200K 9200K - 9400K 9400K - 9600K 9600K - 9800K 9800K - 10000K	000 - 010 010 - 017 017 - 024 024 - 031 031 - 038 038 - 045 045 - 052 052 - 059 059 - 066 066 - 073 073 - 080 080 - 087 087 - 094 094 - 101 101 - 108 108 - 115 115 - 122 122 - 129 129 - 136 136 - 143 143 - 150 150 - 157 157 - 164 164 - 171 171 - 178 178 - 185 185 - 192 192 - 199 199 - 206 206 - 213 213 - 220 220 - 227 227 - 234 234 - 241 241 - 249 249 - 255
3	HUE 0 -25°~25°	000 - 000 001 - 255
4	COLOR MACRO No Function Amber Shift on Color Macro	000 - 002 003 - 005 006 - 255
5	DIMMER SPEED MODE Preset dimmer speed from display menu Dimmer speed mode off Dimmer speed mode1 (fast speed) Dimmer speed mode2 (middle speed) Dimmer speed mode3 (slow speed)	000 - 051 052 - 101 102 - 152 153 - 203 204 - 255

5 CANALI

MODE 5 Ch2	FUNCTION	DMX Value
1	DIMMER 0~100%	000 - 255
2	DIMMER FINE 0~100%	000 - 255
3	CTO 2800K - 3000K	000 - 010
	3000K - 3200K	010 - 017
	3200K - 3400K	017 - 024
	3400K - 3600K	024 - 031
	3600K - 3800K	031 - 038
	3800K - 4000K	038 - 045
	4000K - 4200K	045 - 052
	4200K - 4400K	052 - 059
	4400K - 4600K	059 - 066
	4600K - 4800K	066 - 073
	4800K - 5000K	073 - 080
	5000K - 5200K	080 - 087
	5200K - 5400K	087 - 094
	5400K - 5600K	094 - 101
	5600K - 5800K	101 - 108
	5800K - 6000K	108 - 115
	6000K - 6200K	115 - 122
	6200K - 6400K	122 - 129
	6400K - 6600K	129 - 136
	6600K - 6800K	136 - 143
	6800K - 7000K	143 - 150
	7000K - 7200K	150 - 157
	7200K - 7400K	157 - 164
	7400K - 7600K	164 - 171
	7600K - 7800K	171 - 178
	7800K - 8000K	178 - 185
	8000K - 8200K	185 - 192
	8200K - 8400K	192 - 199
	8400K - 8600K	199 - 206
	8600K - 8800K	206 - 213
	8800K - 9000K	213 - 220
	9000K - 9200K	220 - 227
	9200K - 9400K	227 - 234
	9400K - 9600K	234 - 241
	9600K - 9800K	241 - 249
	9800K - 10000K	249 - 255
4	COLOR MACRO No Function Amber Shift on Color Macro	000 - 002 003 - 005 006 - 255
5	DIMMER SPEED MODE Preset dimmer speed from display menu Dimmer speed mode off Dimmer speed mode1 (fast speed) Dimmer speed mode2 (middle speed) Dimmer speed mode3 (slow speed)	000 - 051 052 - 101 102 - 152 153 - 203 204 - 255

7 CANALI

MODE 7 Ch	FUNCTION	DMX Value
1	RED	000 - 255
2	ORANGE	000 - 255
3	GREEN	000 - 255
4	ROYAL BLUE	000 - 255
5	BLUE	000 - 255
6	LIME	000 - 255
7	DIMMER SPEED MODE Preset dimmer speed from display menu Dimmer speed mode off Dimmer speed mode1 (fast speed) Dimmer speed mode2 (middle speed) Dimmer speed mode3 (slow speed)	000 - 051 052 - 101 102 - 152 153 - 203 204 - 255

9 CANALI

MODE 9 Ch	FUNCTION	DMX Value
1	DIMMER	000 - 255
2	RED	000 - 255
3	ORANGE	000 - 255
4	GREEN	000 - 255
5	ROYAL BLUE	000 - 255
6	BLUE	000 - 255
7	LIME	000 - 255
8	STROBE No Function Strobe slow to fast	000 - 010 011 - 255
9	DIMMER SPEED MODE Preset dimmer speed from display menu Dimmer speed mode off Dimmer speed mode1 (fast speed) Dimmer speed mode2 (middle speed) Dimmer speed mode3 (slow speed)	000 - 051 052 - 101 102 - 152 153 - 203 204 - 255

12 CANALI

MODE 12 Ch	FUNCTION	DMX Value
1	DIMMER 0~100%	000 - 255
2	STROBE No Function Strobe slow to fast	000 - 010 011 - 255
3	RED	000 - 255
4	ORANGE	000 - 255
5	GREEN	000 - 255
6	ROYAL BLUE	000 - 255
7	BLUE	000 - 255
8	LIME	000 - 255
9	CTO 2800K - 3000K 3000K - 3200K 3200K - 3400K 3400K - 3600K 3600K - 3800K 3800K - 4000K 4000K - 4200K 4200K - 4400K 4400K - 4600K 4600K - 4800K 4800K - 5000K 5000K - 5200K 5200K - 5400K 5400K - 5600K 5600K - 5800K 5800K - 6000K 6000K - 6200K 6200K - 6400K 6400K - 6600K 6600K - 6800K 6800K - 7000K 7000K - 7200K 7200K - 7400K 7400K - 7600K 7600K - 7800K 7800K - 8000K 8000K - 8200K 8200K - 8400K 8400K - 8600K 8600K - 8800K 8800K - 9000K 9000K - 9200K 9200K - 9400K 9400K - 9600K 9600K - 9800K 9800K - 10000K No Function	000 - 010 010 - 017 017 - 024 024 - 031 031 - 038 038 - 045 045 - 052 052 - 059 059 - 066 066 - 073 073 - 080 080 - 087 087 - 094 094 - 101 101 - 108 108 - 115 115 - 122 122 - 129 129 - 136 136 - 143 143 - 150 150 - 157 157 - 164 164 - 171 171 - 178 178 - 185 185 - 192 192 - 199 199 - 206 206 - 213 213 - 220 220 - 227 227 - 234 234 - 241 241 - 249 249 - 252 253 - 255

12 CANALI

MODE 12 Ch	FUNCTION	DMX Value
10	HUE 0 -25°~25°	000 - 000 001 - 255
11	COLOR MACRO No Function Amber Shift on Color Macro	000 - 002 003 - 005 006 - 255
12	DIMMER SPEED MODE Preset dimmer speed from display menu Dimmer speed mode off Dimmer speed mode1 (fast speed) Dimmer speed mode2 (middle speed) Dimmer speed mode3 (slow speed)	000 - 051 052 - 101 102 - 152 153 - 203 204 - 255

13 CANALI

MODE 13 Ch	FUNCTION	DMX Value
1	RED	000 - 255
2	RED FINE	000 - 255
3	ORANGE	000 - 255
4	ORANGE FINE	000 - 255
5	GREEN	000 - 255
6	GREEN FINE	000 - 255
7	ROYAL BLUE	000 - 255
8	ROYAL BLUE FINE	000 - 255
9	BLUE	000 - 255
10	BLUE FINE	000 - 255
11	LIME	000 - 255
12	LIME FINE	000 - 255
13	DIMMER SPEED MODE Preset dimmer speed from display menu Dimmer speed mode off Dimmer speed mode1 (fast speed) Dimmer speed mode2 (middle speed) Dimmer speed mode3 (slow speed)	000 - 051 052 - 101 102 - 152 153 - 203 204 - 255

16 CANALI

MODE 16 Ch	FUNCTION	DMX Value
1	DIMMER	000 - 255
2	DIMMER FINE	000 - 255
3	RED	000 - 255
4	RED FINE	000 - 255
5	ORANGE	000 - 255
6	ORANGE FINE	000 - 255
7	GREEN	000 - 255
8	GREEN FINE	000 - 255
9	ROYAL BLUE	000 - 255
10	ROYAL BLUE FINE	000 - 255
11	BLUE	000 - 255
12	BLUE FINE	000 - 255
13	LIME	000 - 255
14	LIME FINE	000 - 255
15	STROBE No Function Strobe slow to fast	000 - 010 011 - 255
16	DIMMER SPEED MODE Preset dimmer speed from display menu Dimmer speed mode off Dimmer speed mode1 (fast speed) Dimmer speed mode2 (middle speed) Dimmer speed mode3 (slow speed)	000 - 051 052 - 101 102 - 152 153 - 203 204 - 255

19 CANALI

MODE 19 Ch	FUNCTION	DMX Value
1	DIMMER	000 - 255
2	DIMMER FINE	000 - 255
3	RED	000 - 255
4	RED FINE	000 - 255
5	ORANGE	000 - 255
6	ORANGE FINE	000 - 255
7	GREEN	000 - 255
8	GREEN FINE	000 - 255
9	ROYAL BLUE	000 - 255
10	ROYAL BLUE FINE	000 - 255
11	BLUE	000 - 255
12	BLUE FINE	000 - 255

19 CANALI

MODE 19 Ch	FUNCTION	DMX Value
13	LIME	000 - 255
14	LIME FINE	000 - 255
15	STROBE No Function Strobe slow to fast	000 - 010 011 - 255
16	CTO 2800K - 3000K 3000K - 3200K 3200K - 3400K 3400K - 3600K 3600K - 3800K 3800K - 4000K 4000K - 4200K 4200K - 4400K 4400K - 4600K 4600K - 4800K 4800K - 5000K 5000K - 5200K 5200K - 5400K 5400K - 5600K 5600K - 5800K 5800K - 6000K 6000K - 6200K 6200K - 6400K 6400K - 6600K 6600K - 6800K 6800K - 7000K 7000K - 7200K 7200K - 7400K 7400K - 7600K 7600K - 7800K 7800K - 8000K 8000K - 8200K 8200K - 8400K 8400K - 8600K 8600K - 8800K 8800K - 9000K 9000K - 9200K 9200K - 9400K 9400K - 9600K 9600K - 9800K 9800K - 10000K No Function	000 - 010 010 - 017 017 - 024 024 - 031 031 - 038 038 - 045 045 - 052 052 - 059 059 - 066 066 - 073 073 - 080 080 - 087 087 - 094 094 - 101 101 - 108 108 - 115 115 - 122 122 - 129 129 - 136 136 - 143 143 - 150 150 - 157 157 - 164 164 - 171 171 - 178 178 - 185 185 - 192 192 - 199 199 - 206 206 - 213 213 - 220 220 - 227 227 - 234 234 - 241 241 - 249 249 - 252 253 - 255
17	HUE 0 -25°~25°	000 - 000 001 - 255
18	COLOR MACRO No Function Amber Shift on Color Macro	000 - 002 003 - 005 006 - 255
19	DIMMER SPEED MODE Preset dimmer speed from display menu Dimmer speed mode off Dimmer speed mode1 (fast speed) Dimmer speed mode2 (middle speed) Dimmer speed mode3 (slow speed)	000 - 051 052 - 101 102 - 152 153 - 203 204 - 255